


DC-8 FUEL SYSTEM



NOTE: CENTER WING AUX TANK BOOST PUMPS ACTUALLY ARE LOCATED IN NO. 3 MAIN